

How to Plug an airCube Router into your Home Network using a Separate Power Supply

Outdoor
Radio



POE Power Supply




POE Port

LAN Port

Do Not Use this Port

Back of airCube



5-V Micro-USB Power Supply

Home Network
Direct Wires
(optional)